



Canopy Instructions

1. Using scrap depron provided, cut two strips for the canopy floor.
2. Cut depron for the aft canopy mount.
3. Sand the canopy floor and aft canopy mount to fuselage shape.
4. Trim the clear plastic canopy to fit nicely to the canopy floor and fuselage.
5. Glue the canopy to the depron canopy floor and aft canopy mount with Formula 560 or equivalent canopy glue.

Note: Do *NOT* glue the canopy floor to the fuselage. This assembly is designed to be the forward aircraft hatch for batteries.

